

Instruction Sheet

Follow these instructions to remount **ALL** fryer touch screens into new bezels with SN's beginning 2602-2605 (excluding Intuition & Merco) (see Figure 1).

NOTE: SCAN the QR code linked to track reworked fryers.



Subject: 8263964 Controller (UX) Field Rework Kit Instructions (EMEA)

Models affected: Frymaster Fryer Touch Screens serial #'s 2602-2605 (excluding Intuition and Merco)

8.4.26

1. Remove the two Phillips head screws from the upper left and right corners of the controller (see Figure 2).
2. Slide the controller up to disengage it from the bezel (see Figure 3).
3. Lift the controller out from the bezel (see Figure 4).
4. Lower the controller and rest it on the bottom of the control box (see Figure 5). The black tether on the right will support the controller.
5. Disconnect the RJ45 cable from the SIB board **FIRST** (see Figure 6).
6. Disconnect the ground cable and the speaker cable and the USB cable (if applicable) (see Figure 7).
7. Disconnect the lanyard tether from the frame (see Figure 8) to remove the controller.
8. Relocate the controller away from the fryer.
9. Place something down to protect the controller from getting scratched and lay the affected controller face down on a flat surface (see Figure 9).
10. Using a T-8, T10 or T-15 Torx bit, remove and discard the eight (8) screws attaching the controller frame attachment to the controller bezel (see Figure 9).



Figure 1




Figure 2



Figure 3



Figure 4




Figure 5



Figure 6




Figure 7



Figure 8




Figure 9

11. Remove the controller frame attachment and discard the frame attachment (see Figure 10).
12. Lift up on the controller bezel and carefully remove the controller from the bezel noting the position of the harnesses and discard the bezel (see Figure 11).
13. Lay the new bezel flat with the gasket and studs facing up and the mounting holes in the top left and right corners (see Figure 12).
14. Lay the controller on top of the bezel with the cables oriented as shown (see Figure 13).
15. Lay the new retainer bracket, oriented as shown on top of the controller. **Using supplied nuts, secure the top center and bottom center nuts FIRST.** Secure the remaining nuts to the bezel, do not overtighten (see Figure 14).
16. Attach the lanyard to the provided hole (see Figure 15).
17. Reverse steps 1-7 to reattach the controller to the fryer.
18. Repeat steps for **ALL** other controllers in the battery, to ensure they match.
19. Power on the fryer.
20. Ensure the controller(s) boots up (see Figure 16), if not, check connections.



Figure 10




Figure 11




Figure 12




Figure 13




Figure 14




Figure 15




Figure 16