IMPORTANT

DO NOT THROW AWAY

RETAIN THIS DOCUMENT FOR PROPER INSTALLATION

02/2026

8 1 9 5 2 4 0

FRYER START-UP SERVICE RESPONSIBILITIES

The fryer start-up service has been made available as part of new installations to assure the Store Manager that the fryers are operating properly and at optimum efficiency at the time of store opening. Following is a brief summary of the responsibilities of those involved:

Kitchen Equipment Installer's Responsibilities

1. Uncrate the fryer.
2. Level the fryer.
3. Verify that the line power and fryer rating plate voltages are in agreement and, if so, connect fryer to power. For gas units connect to gas supply.
4. Turn power switch to the "ON" position to verify that the controller boots and immediately turn it off. **CAUTION:** This is a momentary test only. Do not leave the fryer in the "ON" position.
5. Call FRYMASTER service agent representative to alert them that fryer is ready for start-up.
6. Leave the service agent information with the Store Manager to reconfirm the time of start-up with the agent.

NOTE: Since the installer may complete installation prior to power and/or gas being permanently furnished to store and prior to the air flow in the restaurant being balanced, it is the responsibility of the Store Manager to follow-up with the service agent to set up a convenient appointment for the start-up.

Service Agent Responsibilities

1. Wipe out frypots with a clean cloth.
2. Ensure the hood exhaust system is correct for the fryer installed.
3. Fill the fryer with oil.
4. Perform melt cycle test.
5. Perform gas pressure checks (HE GAS FRYERS ONLY).
6. Adjust the combustion air blowers to attain a flame current of 1.7-3.0 µA (microampere) Fenwal (HE GAS FRYERS ONLY).
7. Check voltage and ensure it matches the voltage listed on the rating plate.
8. Let the fryer reach set point and check the recovery time and ensure it doesn't exceed the times listed in the Installation and Operation Manual.
9. If issues are found create a separate work order.
10. Repair/replace any malfunctioning parts and notify FRYMASTER SERVICE at 1-800-551-8633.
11. Provide the Store Manager with a copy of the completed start-up form 819-5689.

The service agent assigned to the area is:

SERVICE AGENT: _____
ADDRESS: _____
PHONE NUMBER: _____

If any coordination problems are encountered, contact the FRYMASTER TECHNICAL SERVICE DEPARTMENT at 1-800-551-8633.