

826-1001, 826-1000 Hi-Limit and Mounting Clips

Follow these instructions to replace a hi-limit or hi-limit mounting clips:

1. Remove screws at sides and back of tilt housing and lift off.
2. Remove existing bulb and heating element screws and clips.
3. Remove plastic bushing holding capillary tube from tilt plate and pull thermostat capillary bulb through hole in the plate.
4. Mark wires going to the thermostat to facilitate reassembly. Remove wires.
5. Remove screws and nuts holding thermostat body to the bracket and remove the thermostat.
6. Insert screws included with kit into mounting holes at each side of the thermostat body. Install nut on each screw and tighten securely. Reinstall the thermostat body on the fryer mounting brackets. Install a second nut on top screw only and tighten securely.
7. Slip new plastic bushing over the bulb and capillary tube and snap bushing into hole in the tilt plate.
8. Install the new bulb mounting clips and heating element clips on the element support bar, using new screws and hardware provided. Secure the capillary tube to upper part of the heating element with S clips.
9. Reconnect wires to thermostat.

In 826-1001		
Part No.	Description	Qty
807-0063	Thermostat	1
807-1025	Bushing, plastic	1
910-2097	Bulb, front bracket	1
910-2096	Bulb, rear bracket	1
810-0419	S-Clip, capillary	2
910-2042	Heating element clamp	2
809-0096	Screw	2
809-0250	Nut	3
809-0518	Screw	2
819-5226	Instructions	1

In 826-1000		
Part No.	Description	Qty
910-2097	Bulb, front bracket	1
910-2096	Bulb, rear bracket	1
810-0419	Capillary clip	2
910-2042	Heating element clamp	2
809-0518	Screw	2
819-5526	Instructions	1

