

FILTER MAGIC II

OUTER PAN COVER RETROFIT INSTRUCTIONS

1. REMOVE THE FILTER PAN ASSEMBLY FROM THE CABINET.
2. REMOVE THE 2 NUTS SECURING THE TUBE COVER TO THE PAN.
3. PULL THE COVER AWAY FROM THE PAN AND DISCONNECT THE 2 HEATER LEADS FROM THE TABS ON THE CONTACTS. DISCARD THE COVER.
4. CONNECT THE HEATER LEADS TO THE TABS OF THE REPLACEMENT COVER (POLARITY IS UNIMPORTANT).
5. PLACE THE COVER OVER THE STUDS ON THE OUTER PAN AND SECURE WITH 2 FLAT WASHERS AND 2 KEPS NUTS.
6. USING A 3/16" (.187) DIAMETER BIT, DRILL THROUGH THE REMAINING 2 HOLES INTO THE PAN.
7. COMPLETE INSTALLATION BY INSERTING THE SUPPLIED SCREWS FROM THE INSIDE OF THE PAN THROUGH THE COVER AND SECURING WITH THE NUTS AND WASHERS SUPPLIED, AS SHOWN IN ILLUSTRATION BELOW.

