

45 SERIES CM-I TO CM-III REMOTE COMPUTER CONVERSION KIT (826-1109) INSTALLATION INSTRUCTIONS

1. Remove thermostat knob.
2. Remove one (1) screw from each end of control panel and remove panel.
3. Disconnect wiring harness from back of panel.
4. Remove lights, switches, and thermostat bezel from old panel and install on new panel.
5. Route cable up from bottom left side of fryer and up through bottom of heat shield in control panel area.
6. Plug new cable end into matching plug on heat shield.
7. Reconnect wiring harness to panel and install new panel.
8. Continue routing cable under left side of fryer next to left front door post.
9. Run cable up back of fryer to the exhaust hood. **NOTE:** Be sure to keep cable away from fryer flue opening and **ANY** areas of excessive heat.
10. Secure cable at various convenient points with ty-wraps.
11. Cable should go behind hood and down to the computer mounting frame.
12. Drill proper size holes in hood to mount computer frame brackets and use enclosed machine screws and nuts to mount frame to hood.
13. Plug cable end plug into matching plug on back of computer frame.

