

INSTALLATION INSTRUCTIONS

MERCO BULB-TYPE HEAT LAMPS

8065278SP, 8065285SP, AND KIT 8261983

1. Locate and mark the centerline of the flue cap.
2. Position the support bracket (8231896) as shown in the illustration below, mark the hole locations, and drill $\frac{1}{8}$ -inch holes. Attach the support bracket to the cabinet back using the six #8 x $\frac{1}{2}$ -inch hex head screws (8090361) provided in the kit.
3. Remove the thumbscrew (8090402) from the heat lamp assembly and slide the lamp support arm into the support bracket. Adjust the lamp assembly to the desired height and secure in place with the thumbscrew.
4. Plug the lamp cord into an outlet of appropriate voltage.

