INSTALLATION INSTRUCTIONS TRAY LOCK KIT 826-1485

- Remove the filter tray from the filter cabinet.
- 2. Remove the existing tray lock assembly from each side of the filter cabinet and discard.
- 3. Assemble the two new tray lock assemblies with the parts indicated and mount in the filter cabinet in place of the assemblies removed in Step 2.
- 4. Important: The 10-32 screw and nut (Items 6 & 7) must be assembled to the tray lock assembly after the new tray locks have been installed and the filter tray has been replaced in the cabinet.

ITEM	QTY.	PART NO.	DESCRIPTION
1	2	9001959	BRACKET, FILTER LOCK
2	2	9001957	LOCK, FILTER
3	2	8090442	SCREW, 10-32 X 7/16
4	2	8090189	WASHER, 1/4" FLAT SAE
5	4	8090059	NUT, 1/4-20 HEX
6	2	8090119	SCREW, 10-32 X 1/2
7	2	8090054	NUT, 10-32 HEX

