

826-1634, Footprint III.5 Brace Installation

Follow steps outlined in the illustration below to install the brace in the Footprint III.5 carriage:

In Kit 826-1634	
Part No.	Description
819-5793	Instructions
200-0469	Brace
809-0412	Screws

