

# MJ45 Millivolt Hi-Limit Kit

## 826-2779

1. Drain oil from the frypot.
2. Remove the existing hi-limit.
3. Clean the threads in frypot's hi-limit port.
4. Attach supplied new wires to the new hi-limit. **DO NOT REUSE THE OLD WIRING.**
5. Apply Loctite to the threads of the new hi-limit and screw into place.
6. Route the new wires from the hi-limit to the thermocouple.

In Kit 826-2779		
Part #	Description	Qty
807-5152	T-stat, 425F Hi Limit millivolt	1
108-2448	Wire, hi-limit millivolt	2
819-6658	Instructions	1
815-8000	Loctite, 6ML	1

