

Frymaster K3000 Installation Kit Instructions

1. Disconnect all power from the fryer.
2. Remove screws securing old controller to fryer.
3. Unplug both harnesses from the back of the controller.
4. Remove controller harness from the interface board.
5. Install white menu strip into left side of new controller. If not using standard menu write menu items on reverse side with a permanent marker prior to installing.
6. Install new controller and bezel.
7. Connect all harnesses following the descriptions on the photos below.
8. Secure green ground wire from the controller to chassis ground in component box.
9. Restore power to the fryer.
10. Follow the steps in the enclosed 819-6662 K3000 Setup Instructions to set up the controller.
11. After setup remove power from the controller by removing the 20 pin plug from the rear of the controller for at least 10 seconds.
12. Secure the new controller to fryer using existing screws. If there was a lift-off bezel removed in step 2, reinstall it now.

In Kit		
Part #	Description	Qty
varies	K3000 Controller	1
varies	Bezel	1
809-0247	Nuts	2
807-4949	Slide Overlay menu strip	1
108-0485	Harness, Locator	1
807-5113	Cable, SMT Computer/Interface w/ Drain Safety	1
809-0449	Screw, #10 x ½ Phillips	2
819-6691	K3000 Kit Install Instructions	1
819-6591	K3000 QR Card	1
819-6647	K3000 Computer Manual	1
819-6662	K3000 Computer Setup Instructions	1
819-6684	K3000 Yum Standards Instructions	1

