

## ATO/AIF/VIB Probe Kit Installation Instructions

ATO/AIF/VIB probes in LOV, FQ and OCF fryers must be positioned with the probe flush with the frypot wall or recessed no more than 1/8" (3mm). See photo below.

Tighten NPT fitting to 15 foot pounds of torque and the compression fitting on the probe to 8 foot pounds of torque (hand tight plus one turn).

