

**NOTE:** MOUNT FAUCET STOP ON FAUCET WITH U-BOLTS PROVIDED. OPEN END OF CHANNEL SHOULD LIMIT MOTION OF FAUCET.

### INSTALLATION INSTRUCTIONS:

1. INSTALL FAUCET ARM ON MOUNTED FAUCET AND POSITION ARM TOWARD FRONT OF UNIT.
2. LOCATE FAUCET STOP ON REAR OF FAUCET. INSTALL 1/4" X 1-1/4" U-BOLT INTO UPPER HOLES ON STOP. INSTALL 1/4-20 NUTS ON U-BOLT AND TIGHTEN FINGER TIGHT.
3. INSTALL 5/16" X 1-3/4" U-BOLT INTO LOWER HOLES ON STOP. INSTALL 5/16-18 NUTS ON U-BOLT AND TIGHTEN.
4. CHECK TRAVEL OF FAUCET ARM TO VERIFY LIMITED MOTION.
5. SECURELY TIGHTEN ALL NUTS TO LOCK FAUCET STOP IN POSITION.

