



826-1792, MJCF, MJ45 Switch Replacement

Follow this wiring diagram to install switch 807-3498 as a power switch on a Frymaster MJCFE or MJ45 fryer.

Wire the new switch, 807-3498, as shown below.


In Kit 826-1792	
Part No.	Description
807-3498	Switch
819-5889	Instructions




The original switch was wired as shown at left. This illustration is included to identify placement of wires on the 807-1404 switch.

Wiring of Original Power Switch


Wire the 807-3498 switch as shown in the diagram (immediately below) when installing as a melt cycle switch on a Frymaster MJCFE or MJ45 fryer. The wiring of the original switch is provided as a reference.



The 9P jumper wire is removed and discarded.



8P and 7P are disconnected from the original switch and spliced together.



The original switch, 807-0046, was wired as shown at left.

Wiring of Original Melt Cycle Switch