

Installation Do's and Don'ts

Shipboard installations are often unique, however, here's a list of do's and don'ts to avoid trouble:

- **Do** ensure the fryer is adequately attached to the deck.
- **Do** ensure the fryer is mounted well away from appliances, which are sprayed with water.
- **Do** mount the remote controller within easy reach of the operator and away from the heat and vapors of the fryer vat and other cooking equipment.
- **Do** remove the 15-pin plug from the controller cable with a pin pusher (part no. 806-4855) before routing it to the fryer and carefully reattach, using the provided diagram in section 7.15 of the manual.
- **Do** check the installation and operation manual for the proper wire size and voltage requirements.
- **Don't** mount the remote controller on the fryer's tilt housing or on the bulkhead above the fryer vat.
- **Don't** cut and splice the remote controller's cable to facilitate routing it to the fryer.



DON'T mount the controller on the fryer's tilt housing or on the bulkhead above the fryer's vat



DO use a pin pusher to remove the 15-pin plug on the controller cable for routing.