

Service Bulletin

Subject: New Square Rotary Actuators

Models: 30lb Electric Touch Screen Fryers


3/24/2023

Frymaster 30lb Electric Touch Screen fryers have switched from the **BLUE** (PN 8075809) and **BLACK** (PN 8075808) rotary actuators to **GRAY** square rotary actuators (PN **130013720**).


When replacing an actuator, it is best to replace with the same type of actuator that was removed.

However, the **GRAY** square rotary actuators can be used for replacements in place of the **BLACK** and **BLUE** rotary actuators that are used on the returns and drains of **Electric 30lb Touch Screen Fryers**. The **GRAY** square rotary actuator can also be used on **some** return valves, on **some** gas touch screen fryers.

The **GRAY** square rotary actuators are held in place with two (2) set screws just like the **BLACK** and **BLUE** rotary actuators (see photo above).



GRAY Square Actuator set screws



Gray Square Actuator attached to drain valve