McDonald's Intuition[™] easyTouch[®] Basic Operation **Turn Fryer ON or OFF** Press and hold for 3 seconds Press and hold button 3 seconds to switch on. Press button to switch off. Select button on desired side of a split vat. Start a Cook Cycle Press the product button to start a cook. The timer will start counting down. 02:52 Cancel a Cook Cycle Press the **RED** "X" button next to the timer. Shake Cancel Shake Alarm Press ✓ button. Remove Cancel an end of Cook (Remove) Alarm Press Remove button. Selecting a Product



with a Different Setpoint

If the product is shaded in black and white (different setpoint), press and hold desired product until screen changes to Changing Setpoint.






Check Temperature and Setpoint

Press 🕔

Displays setpoint and actual temperature.











Cooking with the Intuition[™] easyTouch[®]

Products are shown in the display.

When choosing a product in black and white (different setpoint), press and hold the product button until screen changes to **Changing Setpoint**.





2 Press the product button to begin the cook cycle.



3 Display changes to timer with remaining cook time.



4 Shake is displayed when it is time to shake the fry basket.



5 Press ✓ button to cancel **Shake** alarm.



6 Remove is displayed when the cook cycle is complete.



7 Press the **Remove** button to cancel **Remove** alarm.



A green hold timer button indicates an active hold timer. Hold timers run in the background and are not displayed until the hold timers expire.



9 A red hold timer button indicates an expired hold timer.



The **Hold Timers** screen displays active and expired hold timers. Press the **X** button to cancel the alarm.



