



McDonald's easyTouch[®] Intuition Basic Operation

Turn Fryer ON or OFF



Press and hold button 3 seconds to switch on. Press button to switch off. Select button on desired side of a split vat.




Start a Cook Cycle

Press the product button to start a cook. The timer will start counting down.



Cancel a Cook Cycle

Press the RED "X" button next to the timer.




Cancel Shake Alarm

Press ✓ button.



Cancel an end of Cook (Remove) Alarm

Press Remove button.





Selecting a Product with a Different Setpoint

If the product is shaded in black and white (different setpoint), press and hold desired product until screen changes to **Changing Setpoint**.



Check Temperature and Setpoint

Press Displays setpoint and actual temperature.




Cooking with the easyTouch® Intuition


1 Products are shown in the display.
When choosing a product in black and white (different setpoint), press and hold the product button until screen changes to **Changing Setpoint**.



2 Press the product button to begin the cook cycle.



3 Display changes to timer with remaining cook time.




4 **Shake** is displayed when it is time to shake the fry basket.




5 Press ✓ button to cancel **Shake** alarm.



6 **Remove** is displayed when the cook cycle is complete.



7 Press the **Remove** button to cancel **Remove** alarm.



8 A green hold timer button indicates an active hold timer. Hold timers run in the background and are not displayed until the hold timers expire.



9 A red hold timer button indicates an expired hold timer.



10 The **Hold Timers** screen displays active and expired hold timers. Press the **X** button to cancel the alarm.

