

Instruction Sheet

Follow these instructions to install
Filter Pump Isolators.

**Subject: 8263832 Filter Pump Isolator Kit
Instructions**

8.7.2024

1. Disconnect power from the electrical power supply.
2. If necessary remove the fryer from the hood to gain access to the filter pump motor nuts.
3. Remove the four (4) nuts attaching the filter pump motor to the plate.
4. Install the isolators as shown and reattach the pump motor using the supplied nuts (see Figures 1 & 2).
5. Reverse steps 1-3 to reassemble and return to operation.

In This Kit

Part #	Description	Qty
8161199	ISOLATOR, MOTOR VIBRATION FQ120	4
8090417	NUT, FLNG 1/4-20 SERR	8
8198055	FILTER PUMP ISOLATOR INSTRUCTIONS	1




Figure 1



Figure 2