## **High-Efficiency Gas Fryer Preventive Maintenance**

## With regular maintenance, perform these quarterly:



Cleaning the blower motor ensures even combustion.



The O-rings on the filter pan pickup tube should be changed regularly.



A healthy filter system is essential for a healthy fryer.

WARNING: All power cords to the fryer must be unplugged from the power outlet when the front panel is opened for inspection.

- Check and clean flue; ensure all drip trays are in place and clean.
- Check all electrical connections, ensuring there are no loose wires.
- Inspect cabinet; clean excessive oil.
- Check and replace, as necessary, the heat/blower motor relay.
- Remove and clean blower motor. Re-install. Adjust air shutter on blower motor to 1<sup>1</sup>/<sub>2</sub>" and wait 1 minute. Adjust the air shutter as needed to achieve a red-orange glow.
- Verify accuracy of the temperature probe by measuring the vat temperature next to the temperature probe with a pyrometer. Check it against the displayed temperature. The difference should be no more than ± 5°F.
- Remove and clean gas valve vent tube and reinstall.
- Replace O-rings on filter pan.
- ♦ Check recovery time. Turn the computer off. Press ✓ and enter 1652 when the Code prompt is displayed. Less than 2:25 for gas units and less than 1:40 for electric units is acceptable.
- Check drain valve micro-switches to ensure all activate (listen for click).

If further assistance is needed, please contact Frymaster Technical Support, 1-800-551-8633 or service@frymaster.com, for your nearest local service agency.



4/07